FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

MFW2055YEW00 (White)
MFW2055YEB00 (Black)
MFW2055YEM00 (Monochromatic Stainless)

© 2013 Maytag
Part No. W10452087 Rev. E

CABINET PARTS



CABINET PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W10536933	Service & Wiring Sheet
	W10458271	Energy Guide
	W10405120	Use and Care Guide
	2225623	Icemaker Service Sheet
2		Hinge, Top
	W10546298	Left Hand
	W10546299	Right Hand
3		Roller, Front
	W10359256	Left Hand
	W10359255	Right Hand
4	W10217316	Filter, Water
5	M0108107	Clamp, Tube
6	2262176	Screw
7	489497	Screw
8		Cover, Toe Grille
	W10339257	White
	W10353930	Black
	W10353932	Grey
9	489442	Screw
10	W10141622	Brake, Roller
11	W10449619	Tube, Filter Inlet
12	549193	Clamp, Power Cord
13	489497	Screw
14		Hinge, Center
	W10521411	Left Hand
	W10521409	Right Hand
15	W10450363	Shim, Center Hinge
16	489442	Screw
17		Rail, Center (Not Serviced)
18		Fitting, Water Tube (NOT SERVICED)
19	W10346257	Housing, Water Filter
20		Filler, Corner
	W10283959	White
	W10283960	Black
	W10283961	Grey
21		Grille
	W10300127	White
	W10353933	Black
	W10353935	Grey
22	W10331226	Drum, Toe Grille
24	W10449617	Tube, Filter Outlet
25		Cover, Hinge
	W10465765	Left Hand (White)
	W10465764	Right Hand (White)
	W10465771	Left Hand (Black)
	W10465770	Right Hand (Black)
	W10465768	Left Hand (Grey)
	W10465767	Right Hand (Grey)
26	W10306392	Cover, Water Filter
27	W10444800	Cover, Unit
28		Cabinet (Not a Serviceable Part)
29	1106508	Gasket, Seal
30	W10601149	Fitting, Water Tube
31	488208	Screw
32	W10463317	Tube, Cabinet Water

LINER PARTS


1
2
2
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39

LINER PARTS

Illus. No.	Part No.	Description
1		Liner (Not A Serviceable Part)
2	2197380	Grommet
3	W10468762	Gasket, Evaporator Cover
4	W10360497	Assembly, LED Light
5	W10469878	Housing, Light
6	W10326338	Container, Water Reservoir
7	12466105	Switch, Light
8	W10487766	Assembly, Freezer Wire
9	W10459384	Cover, Control Housing
10	W10464673	Motor, Fan
11	2200509	Blade, Fan
12	W10453580	Housing, Control
13	W10356895	Tower, Multiflow Air
14	W10421353	Assembly, Refrigerator Lighting Wire
15	488208	Screw
16	W10300900	Cover, Evaporator
17	W10317182	Tower, Freezer
18	W10383615	Thermistor, Freezer Evaporator
19	1118894	Switch, Rocker Arm (Refrigerator)
20	W10413160	Cover, Water Reservoir
21	W10426134	Reservoir, Water
22	W10271543	Connector, Water Tube
23	W10425252	Cover, Thermistor
24	W10330850	Grille, Air Filter Bottom
25	W10315189	Filter, Air
26	W10336009	Cup, Screw
27	W10438761	Thermistor, Freezer
28	W10321162	Bracket, Fan Motor
29	489478	Screw
30	2254454	Bracket, Evaporator Fan Rear
31	W10313917	Housing, Freezer Lighting
32	W10313918	Lens, Light
33	W10440814	Socket, Light
34	W10473925	Bulb, Light
35	W10257451	Damper, Electronic Control
36	W10474774	Cover, Damper Housing
37	W10314204	Housing, Damper
38	W10448448	Assembly, Multiflow
39	W10438639	Thermistor, Refrigerator

FREEZER DOOR PARTS



FREEZER DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Freezer (Includes Illus. 3)
	W10353182	White
	W10413530	Black
	W10413531	Stainless
2	W10378263	Pan, Ice
3		Gasket, Door
	W10465758	Beige
	W10465761	Black
	W10465762	Grey
4		Assembly, Handle
	W10360538	White
	W10409179	Black
	W10409180	Stainless

REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Refrigerator (Includes #8)
	W10404369	Left Hand (White)
	W10353181	Right Hand (White)
	W10416544	Left Hand (Black)
	W10413518	Right Hand (Black)
	W10416547	Left Hand (Stainless)
	W10413519	Right Hand (Stainless)
2	2189202	Bracket, Door Stop
3	489276	Screw
4		Thimble
	W10366270	Right Hand
	W10334042	Left Hand
5	W10170766	Badge, Maytag
6	W10470155	Closure, Door
7	W10331764	Bin, Medium
8		Gasket, Door
	W10353189	Beige
	W10413465	Black
	W10413468	Grey
9		Assembly, Handle
	W10252284	White
	W10252285	Black
	W10252288	Stainless
10	W10317224	Compartment, Utility
11	W10372916	Bin, Shallow
12	W10462298	Bin, Low Profile
13		Assembly, Mullion
	W10448918	White
	W10448923	Black
	W10448924	Grey
14	12990302	Screw
15	W10397055	Bracket, Door Stop

UNIT PARTS


22
23
10
5
3
7
2
8
9
20
21
28
25
4
31
32
35
6
34
29
15
30
14
24
11
18
17
26
19
19
16
12
13
33
27
1

UNIT PARTS

Illus. No.	Part No.	Description
1	W10300116	Plate, Unit Mounting
2	2319835	Grommet, Condenser
3	W10342567	Condenser
4	W10436849	Heater, Defrost
5	W10321158	Assembly, Evaporator
6	8533961	Screw
7	W10314195	Shield, Heat
8	W10271541	Connector, Union
9	W10314199	Tube, Drain
10	W10248621	Clip, Condenser
11	W10424230	Wire Assembly, Low Voltage
12	W10336511	Control, Electronic
13	W10370696	Enclosure, Electronic Control
14	10835903	Grommet
15	W10194431	Device, Combination Start (Start Relay and Overload)
16	W10313215	Cover, Electronic Control
17	W10475495	Roller
18	2179826	Axle, Rivet
19	8533859	Screw
20	W10236396	Strap, Compressor
21	W10204187	Strap, Bale
22	W10349514	Cover, Condenser Bottom
23	W10296661	Clip, Bottom Cover
24	W10519112	Valve, Drain
25	W10466213	Tray, Drain
26	VS20001	Tube, Process
27	488500	Screw
28	W10391109	Compressor (Also Order 876765 Tube Kit)
29	W10190413	Drier
30	2169373	Capacitor
31	2315541	Baffle, Air
32	2188874	Motor, Condenser
33	W10390391	Wire Assembly, Unit
34	W10139483	Blade, Fan
35	W10466682	Tube, Suction
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 4.25 oz (R-134A)

ICEMAKER PARTS



ICEMAKER PARTS

Illus. No.	Part No.	Description
1	W10329003	Clamp, Tube
2	488208	Screw
3	628379	Clip, Thermal Fuse
4	2181939	Insert, Tube
5	W10238100	Valve, Inlet
6	W10463317	Tube, Cabinet Water
7	W10237915	Bracket, Water Valve
8	W10289690	Cover, Icemaker
9	489442	Screw
10	W10122527	Assembly, Mold and Heater
11	W10435665	Cup, Water Fill
12	627843	Ejector
13	W10122563	Stripper, Ice
14	2194712	Housing, Support
15	2315522	Retainer, Thermostat
16	628397	Thermostat (Also Order 542369 Cement Alumilastic)
17	W10001280	Screw
18	489276	Screw
19	W10474785	Shut Off Arm
20	W10309400	Wire Assembly, Ice Maker
21	W10279866	Assembly, Dual Valve
22	W10223929	Assembly, Module and Motor
23	489136	Screw
100	W10190952	Icemaker Assembly (Complete)

SHELF PARTS


REFRIGERATOR
1
2
4
5
8
3
10
6
7
10
23
16
15
14
15
12
13
9
11
FREEZER
15
17
15
18
20
21
19
22
18
21
22

SHELF PARTS

Illus. No.	Part No.	Description
1	W10486290	Shelf Assembly, Full (30")
2	W10352270	Assembly, Flip Down Shelf
3	W10468557	Track Rail, Center
4	W10305243	Shelf, Flip Down
5	W10468556	Track Rail, Right Hand
6	W10468555	Track Rail, Left Hand
7	W10370327	Pan, Crisper (16")
8	W10317184	Pan, Crisper (8")
9	W10408748	Holder, Produce Filter
10	W10356846	Humidity Control
11	W10346771	Filter, Produce Preserver
12	W10397907	Assembly, Pantry Deli Pan
13	W10317191	Pantry Rail, Left Hand
14	W10317189	Pantry Rail, Right Hand
15	W10278139	Roller
16	W10411411	Control, Temperature
17	W10555437	Freezer Bin, Upper
18	W10257246	Axle, Roller
19	W10317289	Freezer Basket, Lower
20	W10371538	Shaft, Rack
21	W10277361	Collar, Gear
22		Adaptor, Freezer
	W10397636	Left Hand
	W10397635	Right Hand
23	W10513681	Glass, Pantry Cover

DISPENSER PARTS



DISPENSER PARTS

Illus. No.	Part No.	Description
1		Housing, Dispenser (Not Serviced)
2		Tray, Drip
	W10300448	White
	W10356018	Black
	W10356019	Grey
3	W10300437	Separator
4		Fascia
	W10424427	Silver Mirror
	W10424428	Black
5	W10464483	Assembly, User Interface
6		Cover, Separator
	W10356029	Chromium Frost
7		Assembly, Pad
	W10433547	White
	W10433546	Black
	W10433548	Grey
8	W10465298	Wire Assembly, Dispenser
9	W10356017	Ring, Trim
10	2305235	Assembly, Spigot
11	W10445080	Tube, Water Dispenser

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

Illus. No.	Part No.	Description
	W10413645A	Filter, Water (1/4 turn)
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White
	4392900	Biscuit/Bisque

TORX SCREW WRENCH

Illus. No.	Part No.	Description
	1117510	Torx Key